



CLIPPER CARE



CLIPPER CARE

However good the machine, it will only remain effective if properly cared for. At the end of the clipping season, return the clippers to a specialist to check them over and service them. Always store them in a dry place (make sure they're clean!). The blades should be removed and sharpened before being stored in an oily rag.

Each time you clip, inspect the clippers and check that they are in a fit state to be used next time round.

- Give them a general all-over clean-up. Remove the blades and check the teeth are OK. Always have at least one spare pair of blades.

- Check that the cable is not damaged.

- Clean the air filters if fitted. Unscrew them (1), remove and brush both sides to remove the hair (2). (A brush is supplied with Lister clippers). Look through to see that the gauze in the filters is clear. If necessary, wash in detergent (3). Dry and replace.

